


SiPM readout electronics

Detector

- there are 3 boxes
- each box have 2 layers scintillator, they are located in x,y direction.
- each layer have 10 modules, each module have 4 scintillator bars
- each scintillator bar have 1 SiPMs
- we have $3 * 2 * 10 * 4 = 240$ Scintillator and SiPMs in total



Basic connection

- each layer connect to one FEE and FPGA board
- each FEE and FPGA board have 64 channels, but we only use 40 channels
- each box have 2 FEE and FPGA board
- The FEE and FPGA board get CLK from DAQ and use LVDS send data to DAQ
- One DAQ get 3 boxes data and send to PC
- we can set the coincidence mode and coincidence window in DAQ by configure the switch on the board





SiPM board

- each SiPM board have 4 SiPMs
- each SiPM have 2 signal output, one is positive, one is negative
- SiPM board get HV from connector




Connector board

- each connector board connect to 10 SiPM board
- connector get the cathode signal from SiPM board and send to FEE board
- connector get the anode signal from SiPM board but send it to GND
- connector get the HV from FEE board and send it to SiPM board




- each FEE board have 64 channels, we use 40 channels
- FEE get the cathode signal from connector board, get the HV from DC Voltage source.
- FEE get discharge signal from FPGA board and send the pulse to FPGA board



FPGA board


- each FPGA board have 64 channels, we use 40 channels
- FPGA get the pulse from FEE board and use inner LVDS comparator compare the pulse with threshold, and get the digital signal
- we can adjust the threshold by change the register of DC/DC circuit in FPGA board. usually we set the threshold to 0.2V
- FPGA get the CLK from DAQ board and send the data to DAQ board
- all parameters and feature can be find at "discharge_time_digitalize.v" file



DAQ (Data Acquisition)

- each DAQ board can get data from 16 FPGA board but now we only use 6 FPGA board
- DAQ board get the data from FPGA board, send CLK to FPGA board, compress data and send to PC by UART

- we can set the coincidence mode and coincidence window in DAQ by configure the switch on the board



- DAQ data format
 - FPGA board data output [1024 bit]/[128 byte] per event
 - every 2 byte is one channel data

探测器编号	转接板输入连接器	转接板输出连接器	前端板连接器	FEE标号	FPGA输入信号序号	字节序号
1(左侧)	J1 9	J11 1	J6	C32	SIPM_SIGNAL[22]	48
2	J1 7	J11 3	J6	31	SIPM_SIGNAL[23]	49
3	J1 5	J11 5	J6	30	SIPM_SIGNAL[25]	50
4	J1 3	J11 7	J6	29	SIPM_SIGNAL[24]	51
5	J2 9	J11 9	J6	28	SIPM_SIGNAL[17]	52
6	J2 7	J11 11	J6	27	SIPM_SIGNAL[26]	53
7	J2 5	J11 13	J6	26	SIPM_SIGNAL[16]	54
8	J2 3	J11 15	J6	C25	SIPM_SIGNAL[27]	55
9	J3 9	J11 16	J6	A24	SIPM_SIGNAL[12]	56
10	J3 7	J11 18	J6	23	SIPM_SIGNAL[13]	57
11	J3 5	J11 20	J6	22	SIPM_SIGNAL[10]	58
12	J3 3	J11 22	J6	A21	SIPM_SIGNAL[11]	59
13	J4 9	J12 1	J3	C16	SIPM_SIGNAL[42]	16
14	J4 7	J12 3	J3	15	SIPM_SIGNAL[45]	17
15	J4 5	J12 5	J3	14	SIPM_SIGNAL[44]	18
16	J4 3	J12 7	J3	13	SIPM_SIGNAL[43]	19
17	J5 9	J12 9	J3	12	SIPM_SIGNAL[33]	20
18	J5 7	J12 11	J3	11	SIPM_SIGNAL[32]	21
19	J5 5	J12 13	J3	10	SIPM_SIGNAL[35]	22
20	J5 3	J12 15	J3	C9	SIPM_SIGNAL[34]	23
21	J6 9	J13 1	J4	C1	SIPM_SIGNAL[41]	0
22	J6 7	J13 3	J4	C2	SIPM_SIGNAL[39]	1
23	J6 5	J13 5	J4	C3	SIPM_SIGNAL[38]	2
24	J6 3	J13 7	J4	C4	SIPM_SIGNAL[40]	3
25	J7 9	J13 9	J4	C5	SIPM_SIGNAL[37]	4
26	J7 7	J13 11	J4	C6	SIPM_SIGNAL[46]	5
27	J7 5	J13 13	J4	C7	SIPM_SIGNAL[47]	6
28	J7 3	J13 15	J4	C8	SIPM_SIGNAL[36]	7
29	J8 9	J13 16	J4	A9	SIPM_SIGNAL[50]	8
30	J8 7	J13 18	J4	10	SIPM_SIGNAL[51]	9
31	J8 5	J13 20	J4	11	SIPM_SIGNAL[53]	10
32	J8 3	J13 22	J4	A12	SIPM_SIGNAL[52]	11
33	J9 9	J14 1	J5	C17	SIPM_SIGNAL[20]	32
34	J9 7	J14 3	J5	C18	SIPM_SIGNAL[19]	33
35	J9 5	J14 5	J5	C19	SIPM_SIGNAL[18]	34
36	J9 3	J14 7	J5	C20	SIPM_SIGNAL[21]	35
37	J10 9	J14 9	J5	C21	SIPM_SIGNAL[31]	36
38	J10 7	J14 11	J5	C22	SIPM_SIGNAL[30]	37
39	J10 5	J14 13	J5	C23	SIPM_SIGNAL[28]	38
40	J10 3	J14 15	J5	C24	SIPM_SIGNAL[29]	39

- [channel63high,channel63low....channel0high,channel0low]

- if you find byte100 is 0x22,byte101 is 0x11, it means “字节序号50” , “探测器编号3” channel data is 0x1122
- data compress
 - cosmic ray signal is rare, so we can compress the data by remove the 0 data
 - we can compress one FPGA board data to 8/16 byte
 - data format is
 - 8bit compress[byteaddr0,byte0,byteaddr1,byte1,byteaddr2,byte2,byteaddr3,byte3]
 - 16bit
compress[byteaddr0,byte0,byteaddr1,byte1,byteaddr2,byte2,byteaddr3,byte3,byteaddr4,byte4,byteaddr5,byte5,byteaddr6,byte6,byteaddr7,byte7]
 - notice that is the byte address,if a signal adc value <256,it will only cost 1 byte to store the data,if the adc value >256,it will cost 2 byte to store the data.
 - so in the case of 8 byte compress, we can get 4 channel data at maximum, 2 channel data at minimum
 - in the case of 16 byte compress, we can get 8 channel data at maximum, 4 channel data at minimum
- data pack to User PC(uart)
 - [header(11111100),DAQ0(8/16byte),DAQ1(8/16byte),DAQ2(8/16byte),DAQ3(8/16byte),DAQ4(8/16byte),DAQ5(8/16byte),DAQ6(8/16byte)(0 now),DAQ7(8/16byte)(0 now),end(00000011)]
- user data reconstruct
 - we can use the header and end to get package
 - check package length to filter the data
 - reconstruct the data to get the channel data